


TPS Autofill

The TPS Autofill Liquid Liner System is designed for the hygienic storage and transportation of liquid products.



One of the advantages of Autofill is that it unfolds all by itself during the filling operation. The Autofill liner is stocked in polythylene (PE) as standard. Due to the folding of the Autofill liner, a frontal filling retainer must always be used during filling.

For mounting and operating instructions see overleaf.



www.tpsrentalsystems.com

MAKING SUPPLY CHAIN LOGISTICS AS EASY AS IBC

To see the full range of TPS IBC-related supplies
email: sales@tpsrentalsystems.com
or visit the TPS web site

TPS Autofill

Mounting and Operating Procedure

Before you start:

- Always mount into a front-filling container.
- Begin by folding down the container side (side 1) for access.
- The outer liner sleeve MUST NOT be removed prior to filling.

To mount the Liner into the container:


- 2 Insert the discharge valve of the liner vertically down into the square discharge hole, guiding it until the valve faces out through the discharge hole at the edge of the container.
- 3 Hang the inner liner over the container edge (side 4) then close and lock the open side 1 back into the upright position.
- 4 Place the filling bridge on top of the container. Adjust and fit the slide arms on to the two opposing sides of the container top. Tighten the thumbscrews. Place the liner filling gland into the filling bridge, and lock into position.
- 5 Remove the cap for the filling gland. We recommend this closed system when filling Auto Fill, for optimum hygiene.

To fill the liner:

- 6 When starting to fill, it is important that the product is forced down to the bottom of the inner liner, to avoid accumulation of liquid products underneath the filling gland or at the rear of the container.
- 7 It is recommended to fix or grip around the rear flap of the liner until it has started to unfold, filled with product to around 50 to 100 litres. (The overhang inside the container folds around the bridge arm).

When the liner is full:

- When the container is full, replace the cap firmly. Finally, remove the filling bridge and the outer sleeve from the liner.
- Fold the excess of the liner within the dimensions of the lid before closing the container.
- Prior to discharging the container, fit the wringer to the container attach the liner and wind the handle for a complete discharge.



UNITED KINGDOM

TPS Rental Systems Ltd
Unit 349 Rushock Trading Est.
Nr. Droitwich Worcestershire
WR9 0NR England

T: +44 (0) 1299 253 535
F: +44 (0) 1299 253 433

sales@tpsrentalsystems.com

www.tpsrentalsystems.com



www.tpsrentalsystems.com

MAKING SUPPLY CHAIN LOGISTICS AS EASY AS IBC